

Hot-Link® System for Domestic Hot Water Recirculation


SUPERSEDES: June 1, 2013

EFFECTIVE: June 1, 2014

Plant ID# 001-3917

Application:

The Taco **Hot-Link® System** for Domestic Hot Water recirculation ensures instant hot water comfort at showers and faucets. By supplying fresh hot water to the fixtures while returning the “cooled” hot water back to the water heater through the cold line, it also saves thousands of gallons of wasted water per year. The average family can achieve yearly savings of up to 12,000 gallons of water normally wasted down the drain while waiting for hot water.



High Quality Features:

The **Hot-Link System** includes a high performance Stainless Steel 00 circulator with a pre-wired power cord and programmable 24 hour timer. This circulator is suitable for most residential homes with hot supply lines up to 150 feet in length.


The unique **Hot-Link Valve** is the key to the system. Made of durable high temperature polymer, it creates an easy-to-install return loop through the cold line from the furthest fixture back to the water heater. An integral thermal sensor disc closes when hot water reaches the valve. An internal flow check prevents cold water from backing into the hot line. Stainless steel braided flex hoses complete the installation.

Installing the Hot-Link System Circulator:

WARNING: To avoid electrical shock, disconnect the power supply to the circulator and the main electrical unit.

**WARNING: 1. Circulator must be installed on and supported by the circulation piping.
2. The addition of unions on both the suction and discharge side of the circulator is recommended.**

1. Follow all local plumbing and electrical codes when installing the **Hot-Link System**.
2. Shut off cold water supply valve to water heater.
3. Open a hot water faucet in the house to drain the hot water line.
4. Open water heater drain valve located at the bottom of tank to drain remaining hot water from the lines. It is not necessary to drain the entire tank.
5. Disconnect hot water supply line at water heater outlet nipple.
6. Install one 3/4" tailpiece of the union adapter provided to the water heater outlet. Apply pipe dope or Teflon tape to all male threads as required.
7. Install the other 3/4" union tailpiece to the pump inlet connection. Be sure flow arrow located on the pump casing is in the proper direction. See diagram.



8. Install the stainless steel **Hot-Link** circulator by connecting the union halves. Circulator motor must be in the horizontal position.

CAUTION: Do not run circulator dry. Permanent damage may result and will void warranty.

9. Reconnect the hot water supply line to circulator outlet.
10. Open supply valve to water heater. Let water run until all air is purged from lines. Check for any leaks. If leaks are detected, close supply valve and tighten all connections.
11. Shut off open hot water faucet.





A Taco resource – saving product

Setting the Circulator Timer:

1. Set timer to exact time of day by turning the clock face clockwise. Be sure to align the time arrow with the correct AM/PM settings in outer ring.

Analog Timer Manual Switch Settings

1. Up = On, Constant circulation I
2. Middle = Automatic operation 
3. Down = Off O




Analog Timer Diagram

2. Plug power cord into nearest 115V power outlet. Set timer manual switch to ON to test for pump operation. Run pump in manual mode for 5 minutes to purge air from pump. See clock face diagram.
3. To set the desired ON/OFF operation times, push the trippers away from the clock face at the corresponding hour/minute for ON times. Push trippers toward clock face for OFF times. Each tripper represents 15 minutes.
4. After all ON/OFF times are set, move timer manual switch to middle AUTO position for automatic operation.

Installing the Hot-Link Valve:



1. Select the hot water faucet furthest from the water heater. If your plumbing system branches in two different directions, another **Hot-Link Valve** may need to be installed at the end of each run.
2. Shut off the hot and cold angle stop valves below the sink.
3. Open the hot and cold faucets to purge water from the lines.


 **CAUTION: Do not use pipe dope or teflon tape on the valve body threads.**

4. Disconnect the hot and cold flex hoses from the 1/2" faucet connections beneath the sink and reconnect them to the respective hot and cold inlet ports on the **Hot-Link Valve**. Locate the flow arrows on the side of the valve to verify flow direction.



CAUTION: Use caution when attaching flex hoses to the Hot-Link Valve to prevent cross-threading or stripping of the threads.

5. Install the 1/2" x 1/2" flex hoses provided. Connect one hose to the hot outlet of the valve and the hot water connection on the faucet (left side). Connect the second flex hose to the cold outlet of the valve and the cold water connection on the faucet (right side).
6. When all connections are made, open angle stop valves and check for leaks.
7. Attach the **Hot-Link Valve** to the wall using anchor screws provided.



Note: The **Hot-Link Valve** can be disassembled for service and cleaning. Repeat steps number 2 and 3. Unthread the valve stem from the body and clean internal screen of debris. Reattach valve stem securely to prevent leaks. Open angle stop valves and check for leaks.



Hot-Link Trouble Shooting

SYMPTOM	POSSIBLE CAUSE	SERVICE TIP
No Hot Water	Clogged filter screen.	<ul style="list-style-type: none"> • Close angle stop valves beneath sink. • Open hot and cold faucets to drain line of pressure. • Remove valve stem, thoroughly clean screen, replace, open angle stop valves and check operation.
	Pump installed incorrectly.	<ul style="list-style-type: none"> • Check to see if flow arrow on pump casing is in correct direction.
	Pump not running.	<ul style="list-style-type: none"> • Check circuit breaker. • Check power supply outlet. • Check to see if timer is set to correct time of day. • Check trippers. Are they set to correct AM/PM time? • Check timer switch. Set to AUTO (middle) position.
	Hoses connected incorrectly.	<ul style="list-style-type: none"> • Check to see if flex hoses are connected to proper Hot/Cold ports on valve.
<p>Abundance of Hot Water in Cold Line</p> <p>Note: It is normal for some warm water to be in cold line during recirculation cycle.</p>	<p>If unable to flush the hot water from the cold line by running the cold faucet, it may indicate that the valve is damaged.</p>	<ul style="list-style-type: none"> • Replace valve.
Water is too Hot	Hot-Link system has improved delivery of hot water.	<ul style="list-style-type: none"> • Install mixing valve on water heater outlet. See piping schematic on page 1.

LIMITED WARRANTY STATEMENT

Taco, Inc. will repair or replace without charge (at the company's option) any Taco 00 Series circulator or circulator part which is proven defective under normal use within three (3) years from the date of manufacture.

In order to obtain service under this warranty, it is the responsibility of the purchaser to promptly notify the local Taco stocking distributor or Taco in writing and promptly deliver the subject product or part, delivery prepaid, to the stocking distributor. For assistance on warranty returns, the purchaser may either contact the local Taco stocking distributor or Taco. If the subject product or part contains no defect as covered in this warranty, the purchaser will be billed for parts and labor charges in effect at time of factory examination and repair.

Any Taco product or part not installed or operated in conformity with Taco instructions or which has been subject to misuse, misapplication, the

addition of petroleum-based fluids or certain chemical additives to the systems, or other abuse, will not be covered by this warranty.

If in doubt as to whether a particular substance is suitable for use with a Taco product or part, or for any application restrictions, consult the applicable Taco instruction sheets or contact Taco at (401-942-8000).

Taco reserves the right to provide replacement products and parts which are substantially similar in design and functionally equivalent to the defective product or part. Taco reserves the right to make changes in details of design, construction, or arrangement of materials of its products without notification.

TACO OFFERS THIS WARRANTY IN LIEU OF ALL OTHER EXPRESS WARRANTIES. ANY WARRANTY IMPLIED BY LAW INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS IS IN EFFECT ONLY FOR THE DURA-

TION OF THE EXPRESS WARRANTY SET FORTH IN THE FIRST PARAGRAPH ABOVE.

THE ABOVE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR STATUTORY, OR ANY OTHER WARRANTY OBLIGATION ON THE PART OF TACO.

TACO WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF ITS PRODUCTS OR ANY INCIDENTAL COSTS OF REMOVING OR REPLACING DEFECTIVE PRODUCTS.

This warranty gives the purchaser specific rights, and the purchaser may have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or on the exclusion of incidental or consequential damages, so these limitations or exclusions may not apply to you.

Do your **best work.**

TACO, INC., 1160 Cranston Street, Cranston, RI 02920 Telephone: (401) 942-8000 FAX: (401) 942-2360.
TACO (Canadá), Ltd., 8450 Lawson Road, Unit #3, Milton, Ontario L9T 0J8. Telephone: 905/564-9422. FAX: 905/564-9436.

Visit our web site at: <http://www.taco-hvac.com>

Printed in USA

Copyright 2014

TACO, Inc.