

Owens Corning[™] Aluminum and Vinyl Garage Door **Bottom Seal**

INNOVATIONS FOR LIVING®



Description

Owens Corning[™] Aluminum and Vinyl Garage Door Bottom Weatherstrip is designed to help keep your garage clean and more comfortable by forming a weathertight seal to help protect against drafts, dust, moisture, debris and insects all season long.

A low temperature vinyl seal closes gaps up to $\frac{3}{4}$ " at the bottom of garage door and stays flexible to -30°F. The vinyl seal insert is held in place with a sturdy aluminum extrusion fastened to the bottom of the garage door with included screws.

Recommended for both wood and metal garage doors.

Comes in two sizes: 9' for a single car garage and 18' for a two car garage.

Product Data Sheet

Features Contents

9' Aluminum and Vinyl Garage Door Bottom Seal

- Two—54" long Aluminum Channels
- One—9' (108") long Vinyl Seal
- Color—Extrusion: Silver; Vinyl Seal: Black
- Ten—¾" long ¼" Hex head self-drilling screws

18' Aluminum and Vinyl Garage Door Bottom Seal

- Four—54" long Aluminum Channels
- One—18' (216") long Vinyl Seal
- Color—Extrusion: Silver; Vinyl Seal: Black
- Twenty—¾" long ¼" Hex head self-drilling screws

Benefits

- Helps to keep out drafts, wind driven rain and snow, dust, dirt and leaves, insects and rodents
- Sturdy aluminum extrusion
- Seal closes gaps up to $\frac{3}{4}$ "
- Durable vinyl seal stays flexible to -30°F
- Easy to install

Recommended Tools

- I. Safety Glasses
- 2. Measuring tape
- 3. Hacksaw or jigsaw with blade for cutting aluminum

- 4. Drill and $\frac{1}{4}$ " driver bit or hex head socket wrench/hex driver
- 5. Scissors or cutting knife
- 6. Pencil

Installation Instructions

- Remove old seal from garage door.
- Measure underside of garage door and cut aluminum base and vinyl seal to correct length.
- Center the aluminum base on the garage door bottom and fasten into position with selfdrilling screws.
- Slide vinyl seal into aluminum channels.
- Trim to length.
- Crimp Aluminum channel to hold seal in place.
- Added Note: For garage doors with guide rails: Slide one edge of vinyl into position before fastening aluminum base. Once fastened, insert inside flange of opposite rubber edge, and push outside flange into channel with screwdriver. Begin at either end of aluminum base.

Safety and Precautions

WARNING: CHOKING HAZARD. KEEP OUT OF REACH OF CHILDREN.

Disclaimer of Liability

Technical information contained herein is furnished without charge or obligation and is given and accepted at recipient's sole risk. Because conditions of use may vary and are beyond our control, Owens Corning makes no representation about, and is not responsible or liable for the accuracy or reliability of data associated with particular uses of any product described herein. Nothing contained in this bulletin shall be considered a recommendation



OWENS CORNING INSULATING SYSTEMS, LLC ONE OWENS CORNING PARKWAY TOLEDO, OHIO, USA 43659 1-800-GET-PINK®

Pub. No. 10013876. Printed in U.S.A. July 2011. THE PINK PANTHER[™] & ©1964–2011 Metro-Goldwyn-Mayer Studios Inc. All Rights Reserved. The color PINK is a registered trademark of Owens Corning. ©2011 Owens Corning.



INNOVATIONS FOR LIVING® www.owenscorning.com