Thunder Mount System

Overhead Garage Door Opener Mounting Instructions rev 11,2011.244

Tools/Items Needed:

- 9/16 socket and wrench
- 1/2" socket and wrench and a ratchet wrench
- Power Drill socket driver 1/8 inch drill bit
- Six foot ladder
- Contact Cement
- Measuring Tape
- L- Square

IN THE BOX:

Figure 1: Instructions 1-Channel, 2 Cradle's, 2 adjustable shaft parts, 1 Isolators, 1 chrome rings, Hardware.



Channel Mounting Hardware



Channel





Cradle's.

Cradle Hardware



IN THE BOX: cont.





Shaft's Hardware & Chrome Ring



Adjustable Shaft's



Thunder Mount Multi-fit Base.

Thunder Mount Base Hardware





Thunder Mount: Mounting above the Ceiling

Lay out all hardware in the order to be assembled."This Saves Time"



#1 Base #2 Channel #3 Cradles #4 Adjustable Shafts.

1. Locate the joists above the ceiling (solid wood supports) where the Thunder Mount channel will be attach. Thunder Mount's patented channel and cradle design is able to be placed in one of two directions (depending on how your house is built) and the cradles can be attached in one of two directions and anywhere along the channel to easily center the opener.



Mark Hole. Cut Hole Cradle's





facing each other.



Thunder Mount: Mounting above the ceiling.







2. Directly below the channel cut a 2.5/8" inch hole at the exact location for the Shaft to go through the ceiling / drywall.



As Seen here a Thunder Mount System Channel Mounted above the supports.

- 3. Attach the cradles to the channel facing each other above the hole where the shafts pass through the ceiling and where The channel can be supported securely. #2 hardware.
- 4. Drill 1/8 x 1 inch deep holes in the structure to attach the Channels. Place the Isolation strip below the channel by cutting them in half and placing the half's at the point in between where the Channel meets the supports. #2 hardware.



Thunder Mounts: Mounting above the ceiling cont.: Rev 11, 2011.244

Note: It helps to have the hardware go through the holes of the Isolator. Fold and Place the Isolator between the Supports and the Channel. Fasten to tighten to supports well.







- 5. Place the chrome ring over the hole and glue it to the ceiling. (Glue not included, contact cement works best)
- 6. You will need two people to do this next step.

 Attach the shafts to the Cradles by passing the shafts

 Through the ceiling and with the #3 set 2.5 x 9/16th nuts and

 Bolts included in the kit. Secure the nuts and bolts good and

 Tight.
- 7. Attach and Secure Shafts with the nut and bolts Hardware #3.

 Recheck all the nuts and bolts and Re-tighten them.





Thunder Mount System
Thunder Mount System Mounting Below the ceiling: Rev 11, 2011.244

1. Attach Thunder Mounts vibration isolation pad by removing The paper to reveal the sticky side. Attach it to the back of the Channel. Use the isolation washers included to complete the Vibration isolation.







Lay out all the hardware in the order to be assembled.



#1 #2 #3 #4

2. Locate the solid wood supports above from where to attach the Channel. Thunder Mounts Patented Channel and Cradle's design are

Able to be placed in two Directions depending on how your house is Built, and the Cradles can be attached anywhere along the channel. Mark that location and Pre-Drill the holes with a 1/8 inch drill Bit And drill 1" deep.

3. Attach the Channel Square with the door with isolation pad and Washer isolators to Secure support structure (#2) hardware.



Mounting Thunder Mount below the ceiling cont.: Rev 11, 2011

4. Attach the
Cradle's
directly
Above the
Opener. Use
#3 hardware
included in the kit.



5. Attach the shafts to the cradles (#4) hardware.

Adjust the height. Recheck all the nuts and bolts and Secure them well!

See installation process on www.thundermounts.com
Serious Injury and or Property Damage can occur if Installation Instructions are not Followed Properly and Voids Any Warranty.







Thank You for Purchasing a Thunder Mount System

Thunder Mounts Systems Multi-fit Overhead Garage Door Tracks Kits

Also Available and Easy to Install.



Thunder Mount System

Overhead Garage Door Tracks.



