



Vinyl Octagon Window

Installation Instructions

TAFCO Vinyl Octagon Windows are designed to install as you would install any vinyl window.

NEW CONSTRUCTION Use Installation Fin for New Construction. (Fig 1)

Step 1. Prepare opening with 45 degree wood pieces at corners. Make sure you have at least 1/4" extra room over the size of your window. (Fig 2)

Step 2. Drop window into opening (Make sure weep slots are to the OUTSIDE and BOTTOM). (fig 3)

Step 3. Secure window into opening with installation flange using pan head screws through pre-drilled holes. (fig 1)

Step 4. Finish inside as desired



REPLACEMENT

Drill and fasten through sides of window for Replacement into an existing opening. (fig 4)

Step 1. Prepare opening with 45 degree wood pieces at corners. Make sure you have at least 1/4" extra room over the size of your window. (Fig 2)

Step 2. Drop window into opening (Make sure weep slots are to the OUTSIDE and BOTTOM). (fig 3)

Step 3. Secure window through the main frame on the side of the window with screws. (fig 4)

Step 4. Finish inside as desired

