

HOW TO INSTALL DOOR STOP

Things You'll Need:

- Saw (circular, miter, or hand)
- Hammer
- finish nails

Instructions:

1. Measure 1 3/8 inches from the front edge of the door jamb and make a mark. The front edge of the door jamb is the room into which the door will open. Move your tape measure up and down the door jamb, making several of these marks. Do the same for the overhead jamb piece.
2. Measure the space at the top between the two door jambs and cut a piece of doorstop material that length. Secure it to the top door jamb at the marks you made from Step 1 with the 2d finish nails. Be certain that the flat side of the doorstop material is facing the door.
3. Putty, sand and paint or stain