INSTALLATION MANUAL

METAL OUTDOOR PARCEL LOCKER TYPE I

1590 SERIES



5935 CORPORATE DRIVE MANHATTAN, KANSAS 66503

Ph. 800-275-1747 *Fax.* 785-537-2950

www.auth-florence.com


TABLE OF CONTENTS

DESCRIPTION	PAGE
OPL INFORMATION	2
SECURITY TOOL REQUIREMENTS	3
SITE PREPARATION AND PEDESTAL INSTALLATION	4
INSTALLATION OF THE MASTER LOAD ARROW LOCK	6
PARCEL ARROW LOCK INSTALLATION	8
PEDESTAL TO OPL INSTALLATION	10
NUMBER PLACARDS INSTALLATION	12

YOUR ISO 9001 MAILBOX SUPPLIER

OPL INFORMATION

METAL OPL TYPE I 1590 SERIES



1590T1AF

	1590T1AF
INSTALLED HEIGHT	62"
DEPTH	17-7/8"
WIDTH	15-7/8"
WEIGHT (WITHOUT PEDESTAL)	83 LBS
WEIGHT (WITH PEDESTAL)	100 LBS
WEIGHT (WITH LEDESINE)	100 LD3
QTY OF STANDARD COMPARIMENTS	0
QTY OF PARCEL COMPARTMENTS	2
PARCEL COMPARTMENT HEIGHT	19.8"
PARCEL COMPARTMENT WIDTH	12.3"

2

SECURITY TOLL REQUIREMENTS METAL OPL TYPE I 1590 SERIES

IMPORTANT NOTICE FOR U.S.P.S. INSTALLERS

INSTALLER MUST ORDER McGARD SCREW DRIVER
(U.S.P.S. - MAIL EQUIPMENT SHOP PART NUMBER 110050)
TO INSTALL AND SERVICE THE PARCEL DOOR ARROW LOCK COVER
ON THE FLORENCE OPL.

IF THE

McGARD SCREW DRIVER MES NO. 110050


NEEDS TO BE ORDERED IT MAY BE ORDERED BY FAXING AN "OFF CATALOG" eBUY REQUEST TO:

> U.S.P.S. MAIL EQUIPMENT SHOP FAX NO. (202) 281-2643



QUESTIONS? CALL THE U.S.P.S. MAIL EQUIPMENT SHOP AT (202) 281-2620

SITE PREPARATION AND PEDESTAL INSTALLATION METAL OPL TYPE I 1590 SERIES



93421_OPL_INSTALL FM PART # 93421 Rev -

REQUIRED; BASE NOT TO EXCEED 16'-0"


WITH ADJOINING SURFACES IN


PAVED AREAS.


SITE PREPARATION AND PEDESTAL INSTALLATION

METAL OPL TYPE I 1590 SERIES

NOTE:
CONCRETE SHALL HAVE A
COMPRESSIVE STRENGTH OF
3000 PSI @ 28 DAYS, CONTAIN
4% MIN. ~ 6% MAX AIR
ENTRAPMENT AND BE
PLACED WITH A 3.50 ~ 4.50"
SLUMP IN ACCORDANCE TO
301.







INSTALLATION OF MASTER LOAD ARROW LOCK


METAL OPL TYPE I 1590 SERIES


TO BE INSTALLED BY AUTHORIZED U.S.P.S. PERSONNEL ONLY

- OPEN ARROW LOCK DOOR.
- REMOVE FIVE (5) 86091 10-32 LOCK NUTS WITH 92303 LOCK SUPPORT PLATE (DISPOSE OF PLASTIC SHIPPING SPACER).
- **3** PLACE ARROW LOCK IN ONE (1) PH92300-F ARROW LOCK SECURITY BRACKET AND POSITION ON DOOR.
- REPLACE ONE (1) 86091 10-32 LOCK NUT IN THE REAR POSITION TO SECURE 92300 ARROW LOCK SECURITY BRACKET.
- 5 INSTALL 92303 LOCK SUPPORT PLATE AS SHOWN.
- REPLACE FOUR (4) 86091 10-32 LOCK
 NUTS. TORQUE 25 TO 30 INCH-POUNDS
 (OVERTIGHTENING MAY KEEP ARROW
 LOCK FORM OPERATING CORRECTLY).

PART #	DESCRIPTION
86091	10-32 LOCK NUT
92303	LOCK SUPPORT PLATE
	ARROW LOCK (PROVIDED BY
	U.S.P.S.)
PH92300-F*	ARROW LOCK SECURITY BRACKET
K92300	KIT ARROW LOCK SECURITY
	BRACKET (INCLUDES LOCK NUTS,
	LOCK SUPPORT PLATE & SECURITY
	BRACKET)
	*ONLY AVAILABLE IN K92300

REQUIRED TOOLS
3/8" SOCKET WRENCH





PARCEL ARROW LOCK INSTALLATION METAL OPL TYPE I 1590 SERIES

TO BE INSTALLED BY AUTHORIZED U.S.P.S. PERSONNEL ONLY

OPEN PARCEL DOOR AND LOCK PARCEL DOOR CUSTOMER LOCK.


NOTE: PARCEL DOOR CUSTOMER LOCK MUST BE IN THE LOCKED POSITION FOR KEY TO BE REMOVED.

- POSITION 64042-SS PARCEL DOOR LOCK STIFFENER ON THE PARCEL DOOR BOLTS AS ORIENTED IN ILLUSTRATION.
- 3 INSTALL ARROW LOCK AS SHOWN, SECURING WITH FOUR (4) 86455 10-32 THIN LOCK NUTS. TORQUE 25 TO 30 INCH-POUNDS (OVERTIGHTENING MAY KEEP ARROW LOCK FORM OPERATING CORRECTLY).
- POSITION 64216-SS PARCEL DOOR
 ARROW LOCK COVER, SECURING WITH
 TWO (2) 84993 10-32 18-8 SS PASSIVATED
 MCGARD FASTENERS.

NOTE: THESE FASTENERS REQUIRE A MCGARD SCREW DRIVER, (SEE PAGE 3).

PART #	DESCRIPTION
64042-SS	SS PARCEL DOOR LOCK STIFFENER
	ARROW LOCK (PROVIDED BY
	U.S.P.S.)
86455	10-32 THIN LOCK NUT
64216-SS	SS PARCEL DOOR ARROW LOCK
	COVER
84993	10-32 x .312 18-8 SS PASSIVATED
	MCGARD FASTENER
K64216-SS	KIT PARCEL LOCK COVER SS
	(INCLUDES SS PARCEL DOOR
	ARROW LOCK COVER, SS PARCEL
	DOOR LATCH MECHANISM COVER
	AND HARDWARE)

REQUIRED TOOLS
U.S.P.S. PROPRIETARY MCGARD TOOL
3/8" SOCKET WRENCH OR NUT DRIVER



PEDESTAL TO OPL INSTALLATION METAL OPL TYPE I 1590 SERIES


WARNING: UNIT IS TOP-HEAVY. PEDESTAL SHOULD BE MOUNTED TO PAD BEFORE INSTALLING CABINET.

- OPEN MASTER LOADING DOOR.
- REMOVE 91079 FLOATING SHELF, EXPOSING MOUNTING HOLES.
- PLACE UNIT ON ONE (1) 91121 PEDESTAL.
- FROM UNDERNEATH UNIT, INSERT FOUR (4) 86101 3/8-16 X 1.25 CARRIAGE BOLTS UPWARD.
- FROM INSIDE PARCEL COMPARTMENTS, ADD FOUR (4) 86097 3/8" X .688 OD LOCK WASHER AND TIGHTEN FOUR (4) 86089B 3/8-16 HEX NUTS. TORQUE TO 22 FOOT-POUNDS.
- **6** REPLACE 91079 FLOATING SHELF.

PART #	DESCRIPTION
91079	FLOATING SHELF
91121	PEDESTAL
86101	3/8-16 X 1.25 CARRIAGE BOLT
86097	3/8" X .688 OD LOCK WASHER
86089B	3/8-16 HEX NUT
K86101-F	KIT HARDWARE PEDESTAL TO
	UNIT MOUNTING (INCLUDES
	CARRIAGE BOLTS, LOCK WASHERS
	AND HEX NUTS)

REQUIRED TOOLS
9/16" SOCKET WRENCH

PEDESTAL TO OPL INSTALLATION



NUMBER PLACARD INSTALLATION METAL OPL TYPE I 1590 SERIES

TO ALLOW FOR ALTERNATE NUMBERING WE SHIP THE NUMBER PLACARDS LOOSE (FOR UNITS THAT ARE NOT ENGRAVED).

IF YOU DESIRE TO USE PLACARDS OTHER THAN PROVIDED '1P' AND / OR '2P', YOU CAN ORDER DIFFERENT NUMBERS FROM YOUR LOCAL AUTHORIZED FLORENCE DEALER. THE OPTIONS RANGE FROM '1P' TO '99P'.

REMOVE ADHESIVE COVER ON BACK
OF PLACARD AND PLACE APPROPRIATE
NUMBER PLACARD IN DOOR EMBOSS.

NOTE: TO ADHERE TO POSTAL REGULATIONS, PLACE THE LOWER NUMBER PLACARD ON THE TOP PARCEL DOOR.

- FOR EACH OF THE (3) THREE 86159 KEY TAGS PER DOOR CLEARLY PRINT THE DOOR PLACARD NUMBER IN SPACE INDICATED ON TAG.
- CHECK KEY OPERATION FOR DOOR AND PLACE 86159 MARKED KEY TAGS IN EACH OF THE CORRESPONDING 86160-3 PLASTIC KEY RINGS AS INDICATED.

PART #	DESCRIPTION
91511-1P	NUMBER PLACARD '1P'
91511-2P	NUMBER PLACARD '2P'
91516	INDIVIDUAL NUMBER PLACARD
	'3P' - '99P'
86159	1 KEY TAG
86160-3	3 KEY RINGED TAG HOLDERS
K86160	KIT TAG HOLDERS W/ TAGS
	(INCLUDES THREE KEY RINGED
	TAG HOLDERS AND THREE KEY
	TAGS)

REQUIRED TOOLS	
PERMANENT FINE POINT PEN	

NUMBER PLACARD INSTALLATION

