










**Assembly Instructions**
**Summer Silhouette™ Glass-Top Dining Table**
**Model # 12255-011**

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. Please read all instructions carefully before starting the assembly process.

**CAUTION:** Some items and/or the components are cumbersome and heavy. Therefore, the assistance of one or more people is recommended in order to prevent personal injury and insure that the item and/or its components are not damaged during the assembly process. Perform all assembly steps on a flat, soft, non-abrasive surface to avoid scratching the finish. Do **not** over-tighten the screws or bolts.


**Hardware & Parts List**

No.	Description	Picture	Qty
A1	Table Top (with glass packed inside)		1
A2	Table Top Frame (with glass removed)		
B	Table Legs		4
C	Screws 1/4"*20		24
D	Washers $\phi$ 6.5*1.0		24
E	Screw Covers 1/4"		24
F	Hex Key		1
G	Touch-up Paint		1

**! KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE !**


## Assembly Instructions

## Summer Silhouette™ Glass-Top Dining Table

Model # 12255-011


**1.** Carefully remove the glass panels that were packed inside of the tabletop frame (A1) for shipping. Next, carefully place the tabletop frame (A2 – with the glass removed) upside down on a flat, soft, non-abrasive surface. Place a table leg (B) in the corner of the table top frame bottom rim and align the holes in the rim with the holes in the table leg. Insert the screws (C) with washer (D) through the holes in the corner of the table rim and screw them into the holes in the table leg. Then, insert screws (C) with washer (D) through the holes on the outside of the table legs and screw them into the holes in the table rim. Do NOT completely tighten any of the screws until all six screws have been inserted. After all six screws have been inserted, use the hex key to securely tighten each screw. Install a screw cover on each of the six screws. See **Figure 1**.

Repeat this same procedure for the other three legs.



**Figure 1**


**2.** After all four legs have been securely attached and the screw covers installed, carefully turn the table over into the upright position. See **Figure 2**.



**Figure 2**

**3.** Carefully place the glass panels, that were removed in Step 1, into the openings in the table top frame. See **Figure 3**.

**Note:** Please keep the touch-up paint (G) for future use on your table if needed.



**Figure 3**


**! KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE !**











**Assembly Instructions**
**Summer Silhouette™ Dining Chair**
**Model # 12255-011**

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. Please read all instructions carefully before starting the assembly process.

**CAUTION:** Some items and/or the components are cumbersome and heavy. Therefore, the assistance of one or more people is recommended in order to prevent personal injury and insure that the item and/or its components are not damaged during the assembly process. Perform all assembly steps on a flat, soft, non-abrasive surface to avoid scratching the finish. Do **not** over-tighten the screws or bolts.

**Note:** The quantities listed in the **Hardware & Parts List** are the totals for all six dining chairs.


**Hardware & Parts List**

No.	Description	Picture	Qty
A	Chair Frames		6
B	Chair Seats		6
C	Long Screws 1/4"*20		24
D	Short Screws 1/4"*15		12
E	Washers $\phi$ 6.5*1.0		36
F	Screw Covers 1/4"		36
G	Seat Cushions		6
H	Back Cushions		6
I	Hex Key		3
J	Touch-up Paint		1


**! KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE !**

## Assembly Instructions

## Summer Silhouette™ Dining Chair

## Model # 12255-011

1. Place the chair frame upside down on a flat, soft, non-abrasive surface. Attach the chair seat (B) to the chair frame (A) by aligning the holes on the chair seat frame rails with those on the chair frame back rail and front legs. Insert the two short screws (D) with washers (E) through the bottom of the chair frame back rail into the holes in the bottom of the chair seat back rail. Insert two long screws (C) with washers (D) through the inside of the corners of the chair seat frame front rail and into the holes in the left leg. Repeat this procedure to attach the chair seat to the right leg. Do NOT completely tighten the screws until all screws have been inserted. After inserting all screws, securely tighten the screws using the hex key (I). Install a screw cover (F) on all of the screw heads both (C & D). See **Figure 1**.




**Figure 1**


2. After securely attaching the chair seat to the seat frame, carefully turn the chair into the upright position as indicated in **Figure 2**. Place the seat cushion (G) and back cushion (H) on the dining chair as shown in **Figure 3**. Secure the seat cushions to the chair frame with the Velcro straps.

Repeat this same procedure to assemble the remaining dining chairs.

**Note:** Please keep the touch-up paint (J) for future use on your chairs if needed.



**Figure 2**



**Figure 3**

**! KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE !**