


Exploded View and Parts List

Air Reciprocating Saw

Model No. CAT823A



Ref.#	Part No.	Description	Qty	Ref.#	Part No.	Description	Qty
1a	CAT823A-RS-01a	Blade, 18 TPI	1	21	CAT823A-RS-21	Pin 2.5×16	1
1b	CAT823A-RS-01b	Blade, 24 TPI	1	22	CAT823A-RS-22	Trigger Pin	1
2	CAT823A-RS-02	Blade Bearing	1	23	CAT823A-RS-23	Spring	1
3	CAT823A-RS-03	Blade Setscrew	2	24	CAT823A-RS-24	Trigger	1
4	CAT823A-RS-04	Blade Chuck	1	25	CAT823A-RS-25	Pin 3×16	1
5	CAT823A-RS-05	Spring	1	26	CAT823A-RS-26	Screw M3×18	4
6	CAT823A-RS-06	Cylinder Cap	1	27	CAT823A-RS-27	Valve Stem Bushing	1
7	CAT823A-RS-07	O-ring 9.5×1.8	1	28	CAT823A-RS-28	O-ring 12.5×1.8	1
8	CAT823A-RS-08	Piston	1	29	CAT823A-RS-29	O-ring 4×1.5	1
9	CAT823A-RS-09	Bumper	1	30	CAT823A-RS-30	O-ring 4.5×1.8	1
10	CAT823A-RS-10	Piston Assembly	1	31	CAT823A-RS-31	Valve Stem	1
11	CAT823A-RS-11	Spring	1	32	CAT823A-RS-32	Spring	1
12	CAT823A-RS-12	Safety Guard	1	33	CAT823A-RS-33	Adjuster	1
13	CAT823A-RS-13	Screw M3×12	3	34	CAT823A-RS-34	O-ring 5.6×1.8	1
14	CAT823A-RS-14	Saw Head	1	35	CAT823A-RS-35	O-ring 11.5×1.6	1
15	CAT823A-RS-15	Setscrew M3×3	2	36	CAT823A-RS-36	Screw Cap	1
16	CAT823A-RS-16	Housing	1	37	CAT823A-RS-37	Washer	1
17	CAT823A-RS-17	Cushion Grip	1	38	CAT823A-RS-38	Air Inlet	1
18	CAT823A-RS-18	Cylinder	1	39	CAT823A-RS-39	Hex Key, 4mm	1
19	CAT823A-RS-19	Gasket	1	40	CAT823A-RS-40	Hex Key, 1.5mm	1
20	CAT823A-RS-20	End cap	1				