

Warning! - Verify design parameters and read notes before use.

The seal on this drawing indicates acceptance of professional engineering responsibility solely for the truss component design shown. The suitability and use of this component for any particular building design is the responsibility of the building designer - not the truss designer or truss engineer, per ANSI/TPI 1-2002 Section 2.

S

A copy of this design shall be furnished to the erection contractor. This design is for an individual building component (a truss). It is based on specifications provided by the component manufacturer and performed in accordance with latest edition of TPI 1, IBC/IRC, and NDS design standards. No responsibility is assumed for the accuracy of information provided by the truss designer. The building designer shall review loading and truss configuration to ensure that this design meets or exceeds minimum loading required by applicable local building codes. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI / TPI 1(National Design Standard for Metal Connected Wood Truss Construction) and BCSI 1-03 (Guide to Good Practice for Handling, Installation & Bracing of Metal Plate Connected Wood Trusses) from the Truss Plate Institute.

Belmont Elevation



