

SALEM 60" X 60" HIGH DINING TABLE

IMPORTANT: PLEASE READ COMPLETE INSTRUCTION SHEET PRIOR TO ASSEMBLY!

Identify all parts packed in carton against the parts list. Remove all protective materials, place parts on a nonabrasive surface to avoid scratching. If any parts are missing or damaged, DO NOT attempt to assemble. Please contact our customer service center (Monday-Friday 9:00 a.m.-5:00 p.m.CST) at 1-877-527-0313 or visit our website at www.homedepot.com.

Step 1

With the help of another person, turn table top (A) upside down on a soft surface. Attach table legs (B) to the table top by inserting bolt (D) with metal washer (E) through the pre-drilled holes in the legs and into the table top. (DO NOT TIGHTEN THE BOLTS COMPLETELY!)

Step 2

Attach leg connector bracket (C) to the table legs by inserting bolt (D) with metal washer (E) through the pre-drilled holes in the leg connector bracket and legs.

Step 3









Using hex wrench (G), tighten all bolts completely and cover them with plastic bolt caps (F). Important note: Each bolt should be tightened a few revolutions at a time, alternating between bolts in a cross corner (X) pattern. This will ensure your table is level by placing equal pressure on all bolt joints. Do not over tighten.

Step 4

Keep touch-up paint (H) for future use for both your table and chairs. Your table is now ready for use. With the help of another person, turn the table in the upright position.

IMPORTANT:

- To avoid damage to your table:
- If using an umbrella, an umbrella base must be used at all times.
 - Make sure the plastic umbrella safety ring is installed in the center of the table before you insert the umbrella pole through the table.
 - Remove the umbrella from the table when not in use or in the event of wind, rain, hail, sleet, snow or any other inclement weather.
 - In storing patio furniture, do not stack anything on glass, stone, or marble tabletops.
 - Before storing, drain all water that may have accumulated in or around patio furniture frames. If not drained properly, water can cause freeze damage.
 - Cover furniture with outdoor furniture covers when not in use.
 - For safety reasons, do not sit or stand on the table.

Parts List							
A	TABLE TOP		1	E	METAL WASHER		16
B	TABLE LEG		2	F	PLASTIC BOLT CAP		16
C	LEG CONNECTOR BRACKET		2	G	HEX WRENCH		1
D	BOLT (M6x20)		16	H	TOUCH-UP PAINT		1

