


SK606 WATER DETECTOR/ALARM : SENSOR NOT DETECTING WATER.

Occasionally, after setting up the SK606 the sensor will not ring (alarm or music) when water is detected. First, ensure that the battery is inserted correctly. Set the unit to MUSIC or ALARM. Wait for the **BEEP** (4-5 seconds). Next, place sensor in direct contact with water. If alarm (or music) does not sound, please perform the following simple step. **This does not void any warranty.** On some units there is a slight build up of plating which inhibits proper detection of water. Switch the unit to the **OFF** position. With a small knife blade, scratch the 2 metal contacts 4-5 times, just enough to scrape a little of the plating off.

Repeat the set up and testing and in most cases the problem is now corrected.



Scratch the 2 metal contacts 4-5 times



Test & repeat if necessary