

Patio Screen 3pcs

PT-SC

Some Assembly Required

***WARNING* Heavy! Handle with care!**

Tools required – Adjustable Wrench and Screwdriver

Parts List:

Lower Left, Center and Right Screen Section	1each
Upper Left, Center and Right Screen Section	1each
Bolts, Lock & Flat Washer, Nut	6sets
Plant Holder Rings	4pcs

- 1st. Start assembly by attaching the 2 center screen sections. They will be the larger sections. Using 2 bolts secure the 2 center sections together. Put a flat washer, a lock washer and nut onto each of the 2 bolts and hand tighten.
- 2nd. Next follow the same procedure for the left and right screen section. Make sure that the hinges are on the same side for the left section and for the right section. Secure them together using Bolts, Flat Washers, Lock Washers and Nut. Hand Tighten only at this point.
- 3rd. Carefully insert the hinge pins on the left and right screen sections in to the hinges of the center section.
- 4th. Using an Adjustable wrench and a Screwdriver tighten all the nut and bolts. Never over tighten as damage may occur.
- 5th. Stand assembled screen upright. Position the Left and Right screen sections at a 45° angle on the hinges from the center section so it stands stable.
- 6th. Clip the Plant Holder Rings to the cross bars of the Patio Screen.

Oxidation of cast iron: The cast iron component of the product is finished with a powder coating process that protects the iron from rusting. However, due to the nature of the iron, rusting is inevitable. It is recommended that the consumer touch up any surface that is scratched or damaged due to wear and tear. Applying an epoxy clear coating is recommended once a year.

Aluminum: The products with aluminum components please be reminded that aluminum is soft metal it is therefore necessary to exercise caution when tightening nuts/bolts/screws on aluminum parts to prevent damaging the treads on the metal.

Solid Brass Fasteners: The fasteners provided are made with solid brass. This item will tarnish after weathering. A brass polish can be use to keep the screws shiny or you can leave it untouched to give it a patina/antique look.

Weathering of wood: The wood component of the product is treated with a penetrating oil stain that is designed to protect from the elements. However, it is recommended to re-stain the wood once a year (depending on the weather conditions in your area) to restore the beauty of the product and to prolong the life of the wood.

Please do not return product to place of purchase – for customer service issues please call 1-866-656-8666 to speak with customer service between the hours of 9am and 5pm Eastern Standard Time. You may also fax or E-Mail any questions or comments to 1-248-652-1105 / sales@oakland-living.com.

5146-20040909