

Please read instructions COMPLETELY before assembly.

ATTENTION:

The canopy is classified as a temporary fabric covered shelter designed primarily for seasonal shade. It is not snow or wind load rated and not recommended as a permanent structure. The canopy must be properly and securely anchored.

WARNING:

Prior to installation, consult with all local and municipal codes regarding the installation of temporary shelters. Choose the location of your shelter carefully. Check for overhead utility lines, tree branches or other structures. DO NOT install near roof lines or other structures that could shed snow, ice or excessive run off onto your shelter. DO NOT hang objects from the roof or support cables. Do not smoke or use open flame devices in or around the shelter. DO NOT store flammable liquids (gasoline, kerosene, propane, etc.) in your shelter. Do not expose top or sides of the shelter to open fire or other flame source. DO NOT use grills, fire pits, deep fryers or smokers inside the shelter. DO NOT use hard-edged tools or instruments like rakes or shovels to remove snow. This could result in punctures to the cover.

CAUTION:

Use CAUTION when assembling this unit. Be aware of unsecured overhead poles. Our canopies are designed to offer protection from damage caused by the sun, light rain, tree sap, bird and animal excrement, and light snow. **It is not designed to hold loads from high winds, heavy snow or ice storms.**

CARE AND CLEANING:

A tight cover will ensure longer life and performance. Always maintain a tight cover. Loose fabric can accelerate deterioration of cover. DO NOT use "Protect and Shine", bleach or harsh abrasive products to clean the fabric cover. Cover can be easily cleaned with mild soap and water.

**THIS IS A TEMPORARY STRUCTURE AND NOT RECOMMENDED
AS A PERMANENT STRUCTURE.**