

TERRACE BAY SQUARE DINING TABLE

IMPORTANT: PLEASE READ COMPLETE INSTRUCTION SHEET PRIOR TO ASSEMBLY! Identify all parts packed in carton against the parts list. Remove all protective materials, place parts on a nonabrasive surface to avoid scratching. If any parts are missing or damaged, DO NOT attempt to assemble. Please contact our customer service center (Monday-Friday 9:00 a.m.-5:00 p.m.CST) at 1-866-538-7735 (fax:952-946-0031), e-mail: custserv@homecasual.net or visit our website at www.homecasual.net.

STEP 1

Insert the table legs into the leg connector bracket. Attach the leg connector bracket (C) to the table legs (B) by inserting the bolts (E) through the pre-drilled holes of the leg connector bracket and legs. (DO NOT TIGHTEN COMPLETELY!)

STEP 2

Turn the table top (A) upside down. Attach 4 table legs (B) to table top (A) by inserting bolts (D) through the pre-drilled holes of the table legs and top. Tighten all bolts completely and cover them with plastic bolt caps (F).

STEP 3

Carefully turn the table in the upright position.

Keep touch-up paint bottle (I) for future use for both your table and chairs .

Your table is now ready for use. Thank you for choosing a Home Casual product!

IMPORTANT: To avoid damage to your table:

- An umbrella base must be used at all times
- Make sure the plastic umbrella safety ring is installed in the center of the table before you
- insert the umbrella pole through the table.
- Remove the umbrella from the table when not in use or in the event of wind, rain, hail, sleet,
- -snow, or any other inclement weather.
- In storing patio furniture, do not stack anything on glass, stone, tile or marble tabletops.
- Before storing, drain all water that may have accumulated in or around patio furniture
- frames. If not drained properly, water can cause freeze damage.
- -Cover furniture with outdoor furniture covers when not in use. - For safety reasons, do not sit or stand on the table.

Parts List							
A	TABLE TOP		1	E	BOLT (M6x25)		8
В	TABLE LEG		4	F	PLASTIC BOLT CAP		12
С	LEG CONNECTOR BRACKET		1	G	ALLEN WRENCH		1
D	BOLT (M6x15)		4	н	TOUCH-UP PAINT BOTTLE		1

