

ITEM #1000 284 983
MODEL #FQS70339C

Wicker Pouf Use and Care Guide

Safety Information

This pouf was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching. Do not locate the product near open flame. Do not use the product as a support. Do not shake, lean or climb on product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.




WARNING: Weight limit for pouf may not exceed 200 lbs. Recommended use for storage and as side table.

Operation

1 Using the wicker pouf

- Always place the pouf on a hard, level surface.
- To open, please remove the lid and cut the rope if needed.
- To close, please place the lid back on and ensure it is secure to the base.

Opening the pouf



Closing the pouf



Warranty

1 YEAR WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product contact the Customer Service Team at 1-877-527-0313 or visit www.HomeDepot.com.


Care and Cleaning

- For best results, clean the frames with damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the pouf in a dry, sheltered place when not in use.
- Keep the pouf away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

For questions or concerns about this product contact the Customer Service Team 8 a.m.- 6 p.m. EST
Monday through Friday at 1-877-527-0313 or visit www.HomeDepot.com.

HOMEDEPOT.COM

Please contact 1-877-527-0313 for further assistance.



ARTÍCULO NÚM.1000 284 983
MODELO NÚM.FQS70339C

Puf de Mimbre

Guía de uso y mantenimiento

Información de seguridad

Este puf fue fabricado con el propósito explícito de usarse como mobiliario de exteriores y no como juguete. Este producto está diseñado para un uso normal en exteriores. Sin embargo, el fabricante recomienda almacenar y/o cubrir este juego cuando se esperan condiciones climáticas adversas. No coloques el producto cerca de llamas expuestas. No utilices el producto como soporte. No sacudas, ni te apoyes o subas sobre el producto. Un adulto responsable debe vigilar en todo momento a los niños menores de 10 años cuando estén cerca del producto. Este producto NO está diseñado para uso comercial y hacerlo anulará la garantía.



ADVERTENCIA: Nunca utilices este producto como soporte. Nunca sacudas, te apoyes o subas sobre el producto.




ADVERTENCIA: El límite de peso por puf no debe superar los 90.7 kg.

Funcionamiento

1 Cómo usar el puf de mimbre

- Coloca siempre el puf sobre una superficie dura y nivelada.
- Para abrir, quita la tapa y corta la soga si es necesario.
- Para cerrar, coloca la tapa nuevamente y cerciórate de que esté asegurada a la base.

Cómo abrir el puf



Cómo cerrar el puf



Garantía

GARANTÍA DE 1 AÑO

QUÉ CUBRE LA GARANTÍA

Le garantizamos al comprador original que el armazón no presentará defectos de fabricación durante un año.

QUÉ NO CUBRE LA GARANTÍA

El cliente es responsable de los costos por flete y empaque desde y hacia nuestro centro de servicio. Esta garantía no cubre daños por uso comercial ni abusivo, herrajes, fenómenos naturales, incendio y congelamiento. Además, las piezas compradas aparte no están cubiertas bajo esta garantía. Nos reservamos el derecho de sustituir el producto por mercancía similar si el modelo en cuestión ya no se fabrica.

Si tiene preguntas o inquietudes acerca de este producto, comuníquese con el equipo de servicio al cliente llamando al 1-877-527-0313 o visite www.HomeDepot.com

Mantenimiento y limpieza

- Para obtener mejores resultados, limpia los armazones con un paño húmedo y sécalos completamente. Esto ayudará a prevenir la aparición de moho al quitar las partículas de polvo que puedan acumularse.
- No limpiar con materiales abrasivos, blanqueador o solventes.
- Guarda el puf en un lugar seco y protegido cuando no esté en uso.
- Mantén el puf alejado del fuego, el calor extremo, condiciones de congelamiento e inclemencias del tiempo como la lluvia, el granizo, el aguanieve, la nieve o el viento.

Si tienes preguntas o inquietudes acerca de este producto, comunícate con el equipo de servicio al cliente de lunes a viernes de 8 a.m. a 6 p.m. (hora estándar del Este), llamando al 1-877-527-0313 o visita www.HomeDepot.com.