

Pet Gazebo Assembly Instructions

1. ASSEMBLE PET GAZEBO WALLS

• Begin with two wall panels. Place **connectors** on the bottom of both ends of one panel. Please note; all **connectors** are identical.



• Insert the second panel into the **connector**. It is important to have the **connector** already attached to the opposite side.



• Attach a **connector** to join the two panels at the top so the unit can stand freely.



 Repeat these steps until you have an octogonal shape, giving attention to the placement of the door panel and the window panel.



2. Assemble Gazebo Roof Supports

• Insert **roof support** arm into the the support hole in the connector.





• Repeat step directly across the opposite side effectively splitting the octogon in half.



• Insert roof support arms into the roof support cap.



• Repeat above two steps. Note; its best to insert **roof support arms** as to make an "x" pattern first.



• Once that is done, you may insert the rest of the roof support arms.

3. Attach Kennel Cover to Pet Gazebo.

- The **kennel cover** is reversable. The white side tends to reflect heat and sunlight and the brown side tends to absorb it.
- Pick which side of the **kennel cover** you wish and then line up the center of the **kennel cover** over the **roof support cap**.



Pet Gazebo Assembly Instructions

• Screw the **roof support topper** to attach **kennel cover** to the kennel.



• Using the ball bands provided attach **kennel cover** to the posts of the kennel. Note; align ribs of the **kennel cover** with the posts of the panels.









Your ADVANTEK Pet Gazebo is now ready for use!








Connecting Multiple Pet Gazebos


- 1. Must have more than one Pet Gazebo. However, no EXTRA parts are needed. Only the ones included with each Pet Gazebo. Detach a single wall panel and its connectors, from a fully completed gazebo.
- 2. Re-attach all four connectors so that it turns the connecting wall panel outward rather than inward. To do this, simply rotate the connectors 180°.



3. Re-attach panel so it is facing outward.



4. Attach Gazebos together into the open connectors.



The possible configurations are endless.

NOTE: For outdoor use ADVANTEK recommends securing your gazebo to the ground for added stability in inclement weather.

WARRANTY

All steel and plastic parts (includes; panels, arms and connectors) are covered with a 5 year warranty. All other parts (cover and ball ties) are covered with a 1 year warranty.

