


Exploded View and Parts List

1/2" Impact Wrench

Model No. HSTC4140

For replacement parts or the nearest service center, call toll free 1-877-841-9438



Ref	Part No.	Description	Qty	Ref	Part No.	Description	Qty
1	HSTC-4140W01	Housing	1	23	HSTC-4140W23	Oil Seal	1
2	HSTC-4140W02	Oil Seal	1	24	HSTC-4140W24	Front End Plate	1
3	HSTC-4140W03	Busing	1	25	HSTC-4140W25	Rotor Blade	6
4	HSTC-4140W04	Spacer	1	26	HSTC-4140W26	Reverse Valve	1
5	HSTC-4140W05	Anvil Collar	1	27	HSTC-4140W27	O-ring (AS014)	1
6	HSTC-4140W06	O-Ring (P7)	1	28	HSTC-4140W28	Steel Ball (1/8")	1
7	HSTC-4140W07	Anvil	1	29	HSTC-4140W29	Spring	1
8	HSTC-4140W08	Spring	1	30	HSTC-4140W30	Regulator Knob	1
9	HSTC-4140W09	Hammer Pin	2	31	HSTC-4140W31	Screw (M4x8)	1
10	HSTC-4140W10	Drive Cam	1	32	HSTC-4140W32	Trigger	1
11	HSTC-4140W11	Drive Cam Base	1	33	HSTC-4140W33	O-ring (2x1)	1
12	HSTC-4140W12	Steel Ball (8mm)	1	34	HSTC-4140W34	Valve Stem	1
13	HSTC-4140W13	Hammer Cage	1	35	HSTC-4140W35	Pin (2.5x24)	1
14	HSTC-4140W14	Pin	1	36	HSTC-4140W36	Pin (3x30)	1
15	HSTC-4140W15	Cylinder	1	37	HSTC-4140W37	Washer	1
16	HSTC-4140W16	Rotor	1	38	HSTC-4140W38	Washer	1
17	HSTC-4140W17	Rear Plate	1	39	HSTC-4140W39	Valve Stem	1
18	HSTC-4140W18	Ball Bearing (6001ZZ)	1	40	HSTC-4140W40	Spring	1
19	HSTC-4140W19	Gasket	1	41	HSTC-4140W41	Exhaust Deflector	1
20	HSTC-4140W20	Rear Cover	1	42	HSTC-4140W42	O-Ring (AS017)	2
21	HSTC-4140W21	Spring Washer & Screw (5x20)	4	43	HSTC-4140W43	Air Inlet	1
22	HSTC-4140W22	Ball Bearing (EE4)	1				