



# Slow Cooker

## FPCP07D7M S

7-Quart Capacity



Pro-Select® Controls	
Buffet	Yes
High	Yes
Keep Warm	Auto
Low	Yes
Mid/Medium	Yes
Soup	Yes
Start/Stop	Yes

### Features

Capacity	7 Quarts
Controls	Pro-Select®
Auto Shut-Off	Yes
Countdown Display	Digital
Digital Display	Yes
Dishwasher-Safe Vessel	Yes
Oven-Safe Vessel	Yes
Delay Start	
Steamer Rack (Reversible)	

### Exterior

Exterior Finish	Brushed Stainless Steel
Vessel Material	Ceramic
Lid Material	Glass
Handle Design	Die Cast

### Specifications

Heating Element Type	Wrap Around
Power Cord Length	3 Feet
Watts @ 120 Volts	280

### Product Dimensions

A - Height	10-1/2"
B - Width	18-1/8"
C - Depth	11-7/8"

### Signature Features



**Pro-Select® LED Display**  
Large and easy to read.




**Pro-Select® One-Touch Options**  
6 preset options including Buffet, Soup, Low, Medium, High and Warm.



**SpaceWise® Design**  
Large 7-quart capacity for cooking flexibility.



**Fully Programmable**  
Select the cooking option, program the time, then Auto Keep-Warm holds the temperature until you're ready.



### FRIGIDAIRE

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • [frigidaire.com](http://frigidaire.com)  
CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [frigidaire.ca](http://frigidaire.ca)  
FPCP07D7M 09/11

© 2011 Electrolux Home Products, Inc.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)

Specifications subject to change.  
Printed in the U.S.A.