HAMPTON BAY SARATOGA HICKORY CARE AND MAINTENANCE INSTRUCTIONS

Please follow the simple instructions outlined below to ensure your Hampton Bay Saratoga Hickory floors look as good in the future as the day they were installed:

General Care Guidelines

- Place walk off mats and area rugs at main entrances to minimize abrasive debris that may be tracked in on shoes.
- Place protective pads under furniture legs and other movable furniture.
- Use protective mats under wheeled office-type chairs.
- Avoid using lacquers, polishes, waxes or detergent based cleaners as they will leave a film/residue on the surface of your Hampton Bay Saratoga Hickory floors and may cause damage beyond repair. The surface of Hampton Bay Saratoga Hickory laminate floors does not require refinishing and will maintain its original appearance.
- Never use abrasive cleaners on your Hampton Bay Saratoga Hickory laminate floors.
- Never flood your floor or wet mop it. Using excessive liquid on your floor may cause plank edges to swell and become damaged beyond repair.
- Never use a steam cleaner on Hampton Bay Saratoga Hickory laminate floors as the steam may cause plank edges to swell and become damaged beyond repair.

Daily Cleaning Guidelines

- For daily cleaning use a dust mop or vacuum with hard surface attachment to remove dust, loose dirt or debris.
- For more thorough cleaning, where a cleaning solution may be required, please use a
 water-based laminate floor cleaner. Alternatively, you can make your own cleaner by
 combining 1 cup of vinegar to 1 gallon of warm water, or 1/3 cup of ammonia to 1
 gallon of warm water.
- To remove stubborn stains, dip a cotton cloth into acetone (nail polish remover) and gently rub the stained area.

FOR ADDITIONAL ASSISTANCE PLEASE CALL CUSTOMER SUPPORT AT 888.864.4520