

Colorfusion Scented Color Changing Candles – (2 Pack)

Colorfusion Candles are the most significant enhancement to happen to the candles in many years. Enjoy this unique candle's traditional flame, fragrance and the special color changing light show. Available in Lavender, Honeydew Melon, Peach, Fresh Linen and Sugar Cookie fragrances.



Size: 3" x 4.25" Round Pillar Candle.

Weight: 1.1 lbs.

Purpose/Product Use:

Home décor, relaxation, room ambience.

Package Contains:

Two individually wrapped candles.

Outdoor / Indoor Suitable:

Suitable for indoor use.

Manufactured:

Thailand and China

Length of time product has been available:

Four years.

Selling Points

Why Buy:

Colorfusion Color Changing Candles are unique and make the perfect holiday gift.

Who Buys:

Candle aficionados and anyone who likes beautiful home décor objects and fragrances.

Key Features & Benefits:

- Beautiful Color Changing Light Show – Enhances the atmosphere of any room.
- Enticing Fragrances – Permeate and freshen the room.
- Color Changing Light Show Operates Lit or Unlit – Flexibility and safety when needed.
- 45 hour burn time / 25 hour battery life – Provides more value than traditional candles.

Differentiation:

Colorfusion Color Changing Candles are patented and offer a unique color changing light show along with traditional flame and fragrance. The effect of flame and color changing enhances the overall candle experience.

Cost Justification:

Colorfusion is a “high tech” candle that incorporates traditional candle technology along with LED electronic technology to form a innovative new candle improvement. Two candles come individually packaged and can be used separately for gifts.

Upsell/Cross-Sell

Other Colorfusion products are available for sale as follows:

- Colorfusion Festival Christmas Candles <2-Pack> – Flameless, Color Changing Candles with Holiday Music
- Colorfusion Spa Deluxe Flameless Relaxation Candle <2-Pack> - Color Changing with 5 Nature Sounds.

Selling Points (cont.)

Return Qualifications:

All returns are to be handled through the proper channels via HomeDepot.com return policy. The Schawbel Corporation will accept returns on all damaged, defective, or unused product. Returns to Home Depot stores are not permitted.

If buyer's remorse, what are most frequently reasons and best counters?

Candle not working – please refer to frequently asked questions.

If damaged, what questions can be asked to see how might buyer/shipper be responsible?

Unit not working if left on and non-replaceable batteries are depleted.

Field Destroy?

No field destroys – The Schawbel Corporation takes back all merchandise that is being returned upon approval.

Warranty Info:

Within one year of purchase, all product may be returned to manufacturer for fixing or replacing. Proof of purchase will be required.

Contact Info:

Please contact HomeDepot.com with any return questions.

Frequently Asked Questions

Q. How do I dispose of the candle?

A. Since the candle is a battery operated product it cannot be incinerated. Please dispose of the candle in accordance with your local laws and regulations for products containing batteries.

Q. What is the candle's burn time and battery life?

A. The candle will burn for 40-45 hours and the light show will last for approximately 25 total hours.

Candle Instructions

Read instructions before use.

Never leave any burning candle unattended.

Keep out of reach of children or pets.

Colorfusion Light Show Operation

- The Colorfusion Candle's light show can operate with or without the candle's flame being lit.
- Use the switch on the bottom of the candle to turn the Colorfusion light show on & off and to “hold” your favorite color:
 - To Turn Color Changing Light Show On: Push the switch on the bottom of the candle for 1 second and release.
 - To Hold on a Favorite Color: Give the switch a quick push while the color glows.
 - To Resume the Color Changing Light Show: Give the switch another quick push.
 - To Turn Color Changing Light Show Off: Hold the switch down until the light show turns off (about 1 second).

Directions For Use:

- Use switch on bottom of candle to turn Colorfusion light show on & off.
- To avoid injury, turn light show on before lighting candle.
- To avoid injury, turn light show off after flame has been extinguished and the wax has hardened.
- Best if viewed in low light conditions.
- Place on heat-resistant surface away from anything flammable.
- Keep wick trimmed to 1/4" or less at all times.
- To prevent a fire hazard, do not allow wick trimmings or matches to accumulate in wax pool.
- Do not move candle while burning or before wax hardens.
- Discontinue use when 2 inches of wax remains.
- **Do Not Incinerate**
- Dispose of candle in accordance with your local laws and regulations for products containing Lithium Manganese Dioxide batteries.