HZ8864A0TX / HZ8864B0TX

Metal/Glass Sliding-Door Display Cabinet




For assistance with assembly, contact:
Southern Enterprises Inc.
Customer Service: 1-800-633-5096
service@seidal.com
www.seidal.com

Assembly Instructions

PO: 13588


Each shelf supports up to lb.




Metal/Glass Sliding-Door Display Cabinet

Parts List

Please review all parts and hardware before disposing of any packaging. Before beginning assembly, separate each type of hardware. Carefully study the diagrams below and check that you have all parts indicated. Call Customer Service if missing hardware. Using incorrect hardware will cause damage. You may receive extra hardware with your unit.





Metal/Glass Sliding-Door Display Cabinet

Assembly Instructions





Figure 1

Note: Do not fully tighten bolts until Step 6 is complete.

Step 1:

Unit assembly should begin with parts turned upside down for Step 1.

Attach Legs (1) to Stretcher (2) using Bolts (A), Spring Washers (B), and Flat Washers (C).



Step 2:

Attach assembled parts to Bottom Frame (3) using Bolts (A), Spring Washers (B) and Flat Washers (C).

Figure 2





Figure 3

Step 3


Attach Left Rear Support (4), Right Rear Support (5), Left Front Support (6), and Right Front Support (7) to Bottom Frame (3) using Bolts (H), Spring Washers (B) and Flat Washers (C).



Step 4

Insert Glass Back Panel (9) along grooves of Left Rear Support (4) and Right Rear Support (5).


Figure 4



Step 5

Insert Glass Side Panels (10) along the grooves of Left Rear Support (4), Right Rear Support (5), Left Front Support (6) and Right Front Support (7).


Figure 5




Step 6

Attach Top Frame (8) to Left Rear Support (4), Right Rear Support (5), Left Front Support (6) and Right Front Support (7) using Bolts (A).

Figure 6





Anti-tipping Hardware

Tip: At least one screw must be directly mounted into a wall stud. Wall anchor is not needed when mounting into a wall stud.

Find ideal location on wall and mark location of each mounting hole.

Using a power drill and a 3/16" drill bit, drill one 3/16" hole on wall.

Note: Make sure not to drill into electrical wiring or plumbing pipes.

Insert Wall Anchor (J) into 3/16" hole. Make sure that wall anchors are flush with wall.

Tip: It may be necessary to use a hammer to gently tap anchors into place.

Attach L Metal Chips **(E)** in pre-drilled holes on back of Left Rear Support **(4)** and Right Rear Support **(5)** using Screws **(G)**.

Attach L Metal Chip **(E)** to Wall Anchor **(J)** using Screws **(K)** and Phillips Screwdriver.

Attach Plastic Straps (**F**) to L Metal Chips (**E**) on wall and Tower.

Now your Metal/Glass Sliding-Door Display Cabinet is ready to use!

Figure 10

Customer Information Name Address City/State/Zip Code Phone Number Please indicate where you purchased this item: Store/Website/Catalog Please indicate color/size/style number: Style No Parts Letter Parts Description Quantity Needed

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

For product issues, please contact Southern Enterprises at 800-633-5096 (toll-free) / 972-869-0111 (Dallas), Mon-Fri 9am – 4pm CST, or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service: 1-800-633-5096

service@seidal.com

Southern Enterprises, Inc. 600 Freeport Parkway, Suite 200 Coppell, Texas 75019