

FOR AGES:

4-10

WEIGHT LIMIT:

150 Lbs
68 Kgs

ADULT(S) NEEDED:



TOOLS NEEDED:



WARNING/ADVERTENCIA

- Do not allow more than one person on this product at any time.
- Children must be supervised by an adult at all times.
- Not recommended for children under 3 years of age.
- The contents of this package are not suitable for children under 3 years of age. Contains small parts which may cause choking.
- ADULT ASSEMBLY REQUIRED.

CUSTOMER SERVICE

-  GQBrands.com
-  CustomerService@GQBrands.com
-  1-866-498-5269
-  4009 Distribution Dr, Suite 240
Garland, TX 75041

CUSTOMER SERVICE INFORMATION

Thank you for purchasing: **LADYBUG JUMPER KIDS TRAMPOLINE**

MODEL# 9022LB

At Global Quality Brands®, we want all of our customers to be completely satisfied with their purchase. Please take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will happily provide replacement parts at no charge within 30 days of purchase.

Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

If you request replacement parts, please be sure to include the following information in your correspondence:

To order these parts, or if you have any other questions or concerns about this GQ Brands product, please contact us at:

PureFun.net
Phone: 1-866-498-5269
Email: customerservice@gqbrands.com
4009 Distribution Dr, Suite 240
Garland, TX 75041

Sincerely,
Customer Service

YOUR NAME:

YOUR MAILING ADDRESS:

YOUR EMAIL ADDRESS:

PRODUCT NAME:

PRODUCT MODEL #:

PART # (Located In Manual)

RETAILER WHERE YOU PURCHASED PRODUCT:

DATE OF PURCHASE:

ORDER # (If Available)

SERIAL#:

QUANTITY NEEDED:

PICTURE OF DAMAGED PART(s) SUBMIT VIA Email, Fax, or Mail

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 90 DAYS FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase, GQ Brands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be preauthorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQ BRANDS® CAN WAIVE OR CHANGE.



IMPORTANT MESSAGE

WARNING - PLEASE READ

ADULT ASSEMBLY REQUIRED

CHOKING HAZARD - Small Parts

NOT for children under 3 years of age.

WARNING:

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

WARNINGS

Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- This unit is designed only for jogging in place and similar bounding exercises.
- Not recommended for children under 3 years of age.
- Maximum weight limit: 150 lbs. (68 kgs)
- Children **MUST NEVER** use the trampoline unless supervised by a responsible adult with knowledge of trampoline use. **DO NOT** leave children unattended at any time.
- Caution and care must be taken in underneath a light or ceiling fan.
- The contents are not suitable for children under 3 years of age. This product contains small parts, which may cause choking.
- This trampoline is designed for one user only. Do not let more than one person use this product at the same time.
- Immediately discontinue use if any breakage to the frame assembly or springs are found. Failure to do this may result injury and/or further damage to the product.
- This trampoline is only designed for normal residential use. It is **NOT** intended for commercial applications and/or in public areas such as schools, parks, day cares, commercial/communal gyms, etc.
- When in use, your trampoline must be placed at a safe distance from any vertical or horizontal obstructions, such as stairways/stairwells, power lines, ceiling fans, pools, walls, overhead or wall light fixtures, windows, furniture, appliances, etc. Keep on a level surface.
- **DO NOT** store trampoline outdoors or where exposed to moisture or extreme temperatures.
- Ensure area under and around trampoline is clear of any toys/obstacles that may cause injury.
- **DO NOT** wear glasses or helmets when using the trampoline.
- **DO NOT** store items, playthings, or place any obstructions underneath the trampoline mat.
- Users should not wear clothing, jewelry, or anything could catch or snag on the product (e.g. loose clothing, cords, shoulder bags).
- **DO NOT** fall or bounce on your knees. This can cause injury.
- **DO NOT** somersault. This can cause serious injury, paralysis, or death.
- **DO NOT** allow infants or animals to crawl underneath the trampoline mat.
- **DO NOT** use or allow use of the trampoline under the influence of any substance or medication which may impair the supervisor's or jumper's judgment and/or coordination.
- Users should stand or bounce as near to the center of the mat as possible. Bouncing or standing near the edge of the trampoline could cause the frame to tip over or damage the mat/springs.
- Do not allow small children to wander into the play area where the trampoline is in use.
- **ALWAYS** secure the trampoline against unauthorized and unsupervised use.
- **ALWAYS** wear socks when using the trampoline
- **NEVER** wear footwear (e.g. shoes) when using the trampoline.
- Before each use, inspect and replace any worn, defective or missing parts. It is important to check the trampoline to ensure the frame is steady and all parts are in good condition.
- Before each use, make sure the frame padding is in place with the springs and frame fully covered.
- **ALWAYS** make sure to store your trampoline safely, where it will not present a tripping or obstacle hazard.
- Dispose of all packaging materials safely and per local ordinance.





















ASSEMBLY WARNINGS

- Make sure the trampoline is placed on a stable and leveled surface.
- Make sure the trampoline area is well lit.
- Make sure there are no obstructions above, beneath, or around the trampoline. In the interest of your safety, it is important that you read both the safety notice and the assembly instructions carefully before using or allowing use of this product.
- Ensure the feet are firmly secured and the frame pad covers the springs before each use.
- If you do not follow these guidelines, the user acknowledges responsibility for the increased risk of serious injury.
- The recommended overhead clearance is a minimum of 10 feet from any and all ceilings, overhead cables, ceiling fixtures or hard surfaces. In terms of horizontal clearance, ensure that potentially hazardous objects and conditions are located at a recommended minimum of 15 feet away from the trampoline (including but not limited to: electric cables, roadways, outdoor equipment, furniture, appliances, vehicles, lighting, walls, tree limbs, shelving, any overhangs, etc.) and no potentially hazardous conditions exist nearby (including but not limited to: stairwells, pools/hot tubs, any bodies of water, uneven or drop-off ground levels, etc.)

PARTS LIST


Part #	Description	QTY	Part#	Description	QTY
1A	Frame	x1	8A	Leg Pole	x6
1B	Jumping Mat	x1	8B	Leg Cap	x6
1C	Spring	x30	9	Straight Pole	x2
1D	W-Hook	x15	10	Left Corner Pole	x1
2	T-Section Piece	x8	11	Right Corner Pole	x1
3	Cross-Section Piece	x4	12	Handler Bar	x1
4	40mm Square Neck Bolt	x14	13	Small Foam Tube	x2
5	50mm Square Neck Bolt	x4	14	Medium Foam Tube	x2
6	Screw Nut	x18	15	Large Foam Tube	x1
7	Frame Pad	x1	16	Plush Face	x1

PARTS LIST



ASSEMBLY INSTRUCTIONS

Assembled Frame



STEP 1:




The Frame (Part 1A), Jumping Mat (Part 1B), Springs (Part 1C), & W-Hooks (Part 1D) will come assembled in one piece.

Place assembled Frame on an even, clean, & flat surface to install. Make sure that there are no obstructions in your way when building this Trampoline.

NOTE:

Make sure that the spring ends are facing up, and the logo printed on the Jumping Mat is facing the floor.




Opening Locations



Identify all openings on the Frame Pad.

There are four sections with 1 opening "A", and two sections with 2 openings "B".

ASSEMBLY INSTRUCTIONS



STEP 2:

Locate x8 T-Section Pieces (Part 2), x4 40mm Square Neck Bolts (Part 4), & x4 Screw Nuts (Part 6).

Locate the (A) openings in the frame (Shown in page 8) to begin installing the T-Sections Pieces into the Frame.

A. Place a T-Section Piece on the outside of the frame and the other half from the inside of the Frame.


All openings will line up. Make sure that the T-Sections are facing up to install the legs in Step 4.

B. Insert a 40mm Square Neck Bolt (Part 4) from the outside of the frame to show the smooth surface. Secure with a Screw Nut (Part 6). Tighten loosely.

NOTE:

Make sure the Bolt is fully inserted and the the Screw Nut is **not** fully tightened. This will help inserting the Legs in Step 4.

ASSEMBLY INSTRUCTIONS




STEP 3:

Locate x4 Cross-Section Pieces (Part 3), x4 40mm Square Neck Bolts (Part 4), and x4 Screw Nuts (Part 6).

Locate the (B) openings in the frame (Shown in page 8) to begin installing the Cross-Sections Pieces into the Frame.


- A. Place a Cross-Section Piece on the outside of the frame and the other half from the inside of the Frame. All openings will line up.
- B. Insert x2 40mm Square Neck Bolts (Part 4) from the outside of the frame to show the smooth surface. Secure both with a Screw Nut (Part 6) on each one. Tighten loosely.




Repeat this process to assemble the second Cross-Section on the Frame.

NOTE:

Make sure Bolt is fully inserted and the Nut is **not** fully tightened. This will help inserting the Legs in Step 4.



ASSEMBLY INSTRUCTIONS




STEP 4:

Locate x6 Leg Poles (Part 8A), x6 Leg Caps (Part 8B), x6 40mm Square Neck Bolts (Part 4), and x6 Screw Nuts (Part 6).


NOTE:

The Leg Poles and Caps might come pre-assembled, to facilitate assembly, separate them. Place the Leg Caps aside.



STEP 5:

Place all Leg Poles (Part 8A) inside the inserts. Align openings from the T-Sections & Cross-Sections to the Legs.



STEP 6:

A. Insert a 40mm Square Neck Bolt (Part 4) from the outside of the Frame and secure tightly with a Screw Nut (Part 6).


B. Secure the Screw Nut tightly also. It is located in the bottom area of the T-Section

Repeat this process until all legs are tightened **only** in the the T-Sections.

NOTE:

Do not tighten the Screw Nuts located in the Cross Sections, this will be explained further in the following step.

ASSEMBLY INSTRUCTIONS



STEP 7:


A. Insert x1 50mm Square Neck Bolt (Part 5) into the upper part of the Cross-Section and secure with a x1 Screw Nut.

B. Tighten loosely with the wrench provided.


Repeat this step on the second Cross Section Pieces

NOTE:

All Screws in the Cross-Sections will be tightened in Step 15



ASSEMBLY INSTRUCTIONS



STEP 8:

A. Flip the Assembled Frame.


Make sure to align the two openings in the Frame Pad (Part 7) assigned for the upper Cross-Section Pieces.

Place on top to cover the Frame & Jumping Mat letting the upper part of the Cross-Section Pieces to show.


B. The Frame Pad is able to stretch to cover the Springs and W-Hooks.

Stretch the Frame Pad to make sure it is snug and properly covering the whole trampoline frame.

C. Flip the frame so the Jump Mat faces the ground and the leg poles are facing up



ASSEMBLY INSTRUCTIONS



STEP 9:

Flip the Assembled Frame. Locate the 3 Loop rings in the "A" sections located in the skirt of the Frame Pad and locate the 4 Strings located in the "B" Sections

A. Grab a loop hole corresponding to the Leg Pole and hook them. Make sure the skirt is properly hiding the legs

Once the loop is hooked to the Leg Pole, insert the Leg Cap (Part 8B).



Repeat these steps to all "A" Sections.

B. Locate the Strings located at the edge of the skirt and at the top of the Frame Pad.


Create a knot on the Leg Pole and a knot on the upper section of the Cross-Section pieces.

Once the strings are tied, insert the Leg Cap (Part 8B).

Repeat these steps to all "B" Sections.




ASSEMBLY INSTRUCTIONS




STEP 10:

Flip the Frame with Frame Pad properly attached

- A. Grab the Plush Face (Part 16) and flip it upside down and align it to the Leg Pole between both Cross-Sections.
- B. On the back of the Plush face there is a sleeve opening. Align it with the corresponding Leg Pole and insert it.
- C. Grab the Leg Cap (Part 8B) and place it into the Leg Pole (Part 8A) to make sure the Plush Face is secure.



ASSEMBLY INSTRUCTIONS



STEP 11:


Align the Velcro fasteners from the edges of the Frame Pad skirt, to the Velcro strips from the Plush Face (Part 16).

Press tightly together and secure the Plush Face to the Frame Pad of the trampoline.

Flip The Trampoline whole and set aside until handle bar is completed



ASSEMBLY INSTRUCTIONS



STEP 12:

- Attach x1 Straight Pole (Part 9) by pressing the snap button at the bottom of x1 Left Corner Pole (Part 10). Insert and push until the button finds a desired opening.
- Select between the two heights options in the Straight Pole for the safest height.
- Slide x1 Small Foam Tube (Part 13) and slide x1 Medium Foam Tube (Part 14)
- Make sure that both foams are pressed against each other to avoid the poles to show.

NOTE:

Failure to properly cover the poles can result in pinching or injury to the user.


STEP 13:

- Attach x1 Straight Pole (Part 9) by pressing the snap button at the bottom of x1 Right Corner Pole (Part 11). Insert and push until the button finds a desired opening.
- Select between the two heights options in the Straight Pole for the safest height.
- Slide x1 Small Foam Tube (Part 13) and slide x1 Medium Foam Tube (Part 14)
- Make sure that both foams are pressed against each other to avoid the poles to show.

NOTE:

Failure to properly cover the poles can result in pinching or injury to the user.

ASSEMBLY INSTRUCTIONS



STEP 14:


Slide Large Foam Tube (Part 15) into the Handle Bar (Part 12) until it stays in the middle of the bar.

Press the snap Button on each side of the Handle Bar and slide until both have found the top openings of the Corner Poles.


Make sure that both foams are pressed against each other to avoid the poles or buttons to show.

NOTE:

Failure to properly cover the poles can result in pinching or injury to the user.



ASSEMBLY INSTRUCTIONS




STEP 15:

- A. Once the completed Handle Bar is assembled, slide both ends of the Straight Poles into the openings of the Cross-Section Pieces.
- B. Insert x1 50mm Square Neck Bolt (Part 5) with the smooth service from the inside of the trampoline.
- C. Secure with x1 Screw Nut (Part 6) from the outside.
- Repeat these steps to secure both sides of the handle bar into the trampoline.

NOTE:

Placing the Bolt from the inside of the trampoline prevents the Screw Nut from being in the way of the jumper. Failure to properly follow this step can result in injury to the user.



FREQUENTLY ASKED QUESTIONS

- Question: "The Handle Bar is not aligned to the Straight Poles, I am unable to Snap & Click since they are not in position"

Answer: Loosen up the upper sections of the Cross-Section Pieces so you may be able to twist the Poles. The bottom opening is wider, which helps position the upper two openings properly. Once you do this, you should be able to insert the Handle Bar.

- Question: "When I am using the trampoline I feel the springs pinching my feet. How do I fix this?"

Answer: 1) There is a chance that the Frame Pad was installed the wrong way. The Spring ends should be facing the floor when in use. 2) When using the trampoline, remember to wear comfortable socks, jumping on the trampoline barefoot is unsafe.

- Question: "The Handrail ends do not point in the right direction, I cannot assemble the center handrail piece, are the holes drilled wrong?"

Answer: If the handle pieces do not seem to be oriented in the correct direction, you may have assembled the handle pieces on the wrong legs. Remove the handle bases and swap the sides they are attached to.

- Question: "One of my trampoline legs has broken" or "The trampoline padding or mat is damaged, how do I replace it?"

Answer: If you are still within your warranty period (90 days from initial purchase) You should contact customer service and request more information.

- Question: "I had a part missing from my box" or "something was damaged during assembly, can you send it to me?"

Answer: If it has been 30 days or less from the date of your initial purchase, you can contact customer service for a replacement part to be issued.