

BB07581

1,000 Lb Motorcycle Stand

Assembly & Operating Instructions



READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING THIS PRODUCT.

This manual provides important information on proper operation & maintenance. Every effort has been made to ensure the accuracy of this manual. These instructions are not meant to cover every possible condition and situation that may occur. We reserve the right to change this product at any time without prior notice.

IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

HAVE QUESTIONS OR PROBLEMS? DO NOT RETURN THIS PRODUCT TO THE RETAILER - CONTACT CUSTOMER SERVICE.

If you experience a problem or need parts for this product, visit our website <http://www.buffalotools.com> or call our customer help line at **1-888-287-6981, Monday-Friday, 8 AM - 4 PM Central Time**. A copy of the sales receipt is required.

FOR CONSUMER USE ONLY - NOT FOR PROFESSIONAL USE.

KEEP THIS MANUAL, SALES RECEIPT & APPLICABLE WARRANTY FOR FUTURE REFERENCE.

BB07581 1,000 Lb Capacity Motorcycle Stand Instructions

FEATURES:

1,000 Lb Max Capacity
Fits Wheel Sizes 15 - 22 Inches
Accommodates Wheel Footprint 3 - 5 Inches
Wheel Locking System For Added Security
Constructed From Powder Coated 12 Gauge Steel

FOR CONSUMER USE ONLY – NOT FOR PROFESSIONAL USE

WARNING

READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below may result in electric shock, fire and/or serious personal injury.

RECOGNIZE SAFETY SYMBOLS, WORDS AND LABELS

What You Need to Know About Safety Instructions

Warning and Important Safety Instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operating or cleaning tools and equipment.

Always contact your dealer, distributor, service agent or manufacturer about problems or conditions you do not understand.

IMPORTANT SAFETY INSTRUCTIONS

WORK AREA

WARNING

- Keep your work area clean and well lit.
- Stay alert, watch what you are doing and use common sense.
- Keep bystanders, children and visitors away while operating. Distractions can cause you to lose control.

USE AND CARE

WARNING

- Always check for damaged or worn parts before using. Do not use if device is damaged, it may cause damage or injury.
- Check to be sure this device fits your vehicle. Your motorcycle wheel should fit properly in the stand. Do not modify this device, or use it for anything other than its intended purpose. Follow all instructions and warnings.
- Do not exceed the 1000-lb. load capacity. Loading a heavier vehicle on the stand can result in personal injury or property damage.
- Mount the motorcycle stand on a clean, level & dry surface. The area where the stand is mounted should easily bear the weight of the operator, motorcycle stand and the vehicle.
- Do not ride the motorcycle onto the stand. Exit from the vehicle, turn of the engine and guide the vehicle onto the stand. Do not sit on the vehicle while it is mounted in the stand.

Assembly

Before beginning device assembly, measure the vehicle wheel. This motorcycle stand is made to accommodate a 15 – 22 inches wheel with a footprint of 3 - 5 inches.

Attach the Leg (11) to the front of the Stand Base (10) by using Bolts (7), Washer (4) and Nut (6).

Set the Wheel Brace (9) inside the Stand Base (10) (refer to the parts diagram for correct placement). Align the pre-drilled holes on the Wheel Brace (9) with the parallel pre-drilled holes closest to the Leg (11). Insert the Long Pin (8) through both sets of holes and secure with a Washer (2) and a R-Pin (1)

Repeat the procedure with the Pivoting Bracket (12). Align the predrilled holes with those furthest from the Leg (11) (refer to the parts diagram for correct placement). Secure with Slide Pin (3), Washer (2) and a R-Pin (1). This can be adjusted later to securely fit the motorcycle wheel.

Check all connections and tighten the hardware. **Securely mount the Motorcycle Stand before use.**

Permanently Mounting Onto Concrete, Truck Bed Or Trailer

After choosing a proper location that can bear the load, use the pre drilled holes on either side of the Leg (11) and Stand Base (10) as a template to mark the spots where the holes will be drilled.

When drilling into concrete, use a masonry or concrete drill bit. Once the holes have been drilled into the concrete, use concrete anchors (not included, available at any hardware store) to secure the base onto the concrete floor.

When mounting onto a truck bed or trailer, be sure that the mounting area is free from wires, or other materials that will affect the operation or structural integrity of the truck or trailer. Attach the stand to the trailer or truck bed with the appropriate hardware (not included, choose hardware based on individual situation/application).

Motorcycle Stand Use

Measure the wheel of the vehicle and choose the correct setting of the Pivoting Bracket (12) on the Stand Base (10) so the wheel and vehicle fit into the Motorcycle Stand properly. Move the Pivoting Bracket (12) to the desired position and secure with the Slide Pin (3), Washer (2) and a R-Pin (1).

To load the motorcycle, flip the Pivoting Bracket (12) flat, and roll the motorcycle onto the stand. The Pivoting Bracket (12) will flip upward, cradle the wheel, and hold the motorcycle.

Secure the motorcycle with belts and straps if transporting. Do not sit on the motorcycle while the vehicle is loaded in the stand.

PARTS LIST AND DIAGRAM

Part	Description	Quantity
1	"R" Pin	4
2	Washer (12)	4
3	SlidePin	1
4	Washer (10)	1
5	Spring Washer	1
6	Nut (M10)	1
7	Bolt (M10 x 30)	1
8	Long Pin	1
9	Part 1	1
10	Part 2	1
11	Leg	2
12	Part 4	1

