
Assembly Instructions

COMPACT BAR • 48" W x 24" D x 38" H



WITH 20 INCH OPENING


CLOSED FRONT

necessories kits for outdoor living



Item	Description	Quantity
4 x 12 x 8"	Large Lakeland Block (L)	44
4 x 8 x 8"	Medium Lakeland Block (M)	36
4 x 4 x 8"	Small Lakeland Block (S)	36
24 x 48" Top	Table Top	1
Cut Block Assembly	Back Splash Arch	5
Adhesive	29 oz. Tubes Super-Stik	3

Lakeland[™] blocks have the sophisticated look of an old brick wall so popular with homeowners today. This tumbled, three piece system offers designers the opportunity and freedom to combine functionality with style. Lakeland blocks can be used to build random-pattern outdoor fireplaces, kitchens, islands, garden and seat walls, pillars, planters, and more.



Large Block


Size: 4" H x 8" W x 12" D

Weight: 31 lbs

Medium Block Size: 4" H x 8" W x 8" D

Weight: 20 lbs.

Μ



Size: 4" H x 4" W x 8" D Weight: 10 lbs.



To build Compact Bar with <u>Closed Front</u>, see page 10.



Copyright notice, please read:

The plans and instructions contained in this kit and the three-dimensional [Compact Bar] design constructed from the use of this kit are protected under the U.S. Copyright Act. Reproduction of the plans, instructions or the [Compact Bar] design, either in whole or in part, and whether in two-dimensional or three-dimensional form, and the creation of new works based upon such plans, instructions or [Compact Bar] design, without the prior written permission of Rockwood Retaining Walls, Inc. is strictly prohibited. The purchase of a genuine kit from Rockwood Retaining Walls, Inc. is strictly prohibited. The purchase the purchaser with a limited license to construct a single [Compact Bar]. Any reproduction of the plans and/or instructions, or the construction of more than a single [Compact Bar] is a violation of Rockwood's copyrights and can result in severe penalties.




Visit us on the web at: www.rockwoodwalls.com


Base Preparation: Base can be constructed of either poured slab or compacted gravel. See requirements below.

Zoning and Permits: Before you plan your project, learn about the necessary zoning requirements and rules for excavating and building in your area. No matter how small your project, be sure you obtain the necessary permits before you start construction.


Know What's Below: Whether you are planning to do it yourself or hire a professional, smart digging means calling 811 before each job. Homeowners often make risky assumptions about whether or not they should get their utility lines marked, but every digging job requires a call – even small projects like planting trees and shrubs.







- 4" deep
- 4" outside perimeter of base
- Reinforce with 6" x 6" no. 10 WWM
- Compact sub-base soils to 95% of standard proctor (ASTM D698)



Aggregate Base Foundation:

- 6" deep
- 8" outside perimeter of base
- Compact sub-base soils to 95% of standard proctor
- Compact aggregate base to 95% of standard proctor (ASTM D698)


Course 1 (For open front)

To build Compact Bar with <u>closed front</u>, see page 10.

Be sure your properly prepared base is level. Begin building by laying your base course as shown.


Using a stiff brush, remove all debris and dust from each block surface to be glued.


IMPORTANT: Lay glue bead away from outside perimeter to prevent glue from squeezing out between courses



Course 2 (For open front)


Continue to build each course as shown. Use adhesive on each block.






Course 4 (For open front)


IMPORTANT: Use Super-Stik adhesive on each course. Brush excessive dust from blocks to be glued.




Course 5 (For open front)




Course 6 (For open front)




Course 7 (For open front)





Course 8 (For open front)




Course 9 (For open front)







Course 11 (For open front)




Course 1 (For closed front)

Be sure your properly prepared base is level. Begin building by laying your base course as shown.


Using a stiff brush, remove all debris and dust from each block surface to be glued.


IMPORTANT: Lay glue bead away from outside perimeter to prevent glue from squeezing out between courses



Course 2 (For closed front)


Continue to build each course as shown. Use adhesive on each block.






IMPORTANT: Use Super-Stik adhesive on each course. Brush excessive dust from blocks to be glued.


Course 4 (For closed front)




Course 5 (For closed front)




Course 6 (For closed front)




Course 7 (For closed front)




Course 8 (For closed front)




Course 9 (For closed front)






Course 11 (For closed front)




Necessories Outdoor Living Kits


Kit specifications, style and availability are subject to change without notice.



Assembly Instructions

COMPACT BAR • 48" W x 24" D x 38" H





WITH 20 INCH OPENING

CLOSED FRONT



A better way.™

325 Alliance Place NE Rochester, MN 55906

toll free 888.288.4045 phone 507.529.2871 fax

507.529.2879

www.rockwoodwalls.com

© 2010 Rockwood Retaining Walls, Inc. All Rights Reserved. Made worldwide under license from Rockwood Retaining Walls, Inc. US and international patents issued and pending. This information has been prepared for the benefit of customers interested in Rockwood Retaining Wall products. It was reviewed carefully prior to publication. Rockwood assumes no liability for its accuracy or completeness. Final determination of the suitability of any information or material for the use contemplated, or for its manner of use, is the sole responsibility of the user. 1110

Available at:

